

1234



FRONT




TOP




BACK

COLOUR

1234




FRONT



TOP

NOTE:


The maximum decoration area is a guide only and is greatly dependant on the logo shape.





BACK

EMBROIDERY / SUPASUB / SUPAETCH / SUPAFLEX

1234



FRONT



BACK

NOTE:

The maximum decoration area is a guide only and is greatly dependant on the logo shape.

SUPACOLOUR / SCREENPRINT